


# INSTRUCTION MANUAL



## FEATURES

- Accurate Japanese Movement
- Stainless Steel Caseback
- Water Resistant
- 3 hand Analog battery powered

## TO SET TIME

1. Pull the crown to the outer position
2. Turn the crown to adjust hour and minute hands

## DIAL DESIGN

Your watch is designed with a faux chrono dial. They do not adjust, they only offer the aesthetic of a chronograph look.

## BATTERY REPLACEMENT

When the second stops ticking it is time to replace the SR626 battery

## FEATURES

Please contact our customer service line with any questions or concerns: [Info@accutimewatch.com](mailto:Info@accutimewatch.com)